




sooka

Quick User Guide

Let's Get Started

1. Plug in sooka TV Stick

Connect the USB cable from the Power Adapter to your sooka TV Stick. Plug your sooka TV Stick into the HDMI port of your TV, then plug the power adapter into a nearby electrical socket.



2. Switch TV Input

Turn on your TV and your sooka TV Stick. Switch to the appropriate HDMI input/source where your sooka TV Stick is plugged into.



TV with HDMI
Input

3. On your remote control, pull out the tab from the remote control battery casing.


4. Your sooka TV Stick LED light status will change to Purple. Follow the on-screen instructions to complete sooka TV Stick setup.



TV with HDMI
Input


5. Start sooka and enjoy!

Safety




- Use only the power adapter provided.
- Insert the power plug firmly.
- Do not touch the main body, power cable or power adapter with wet hands.
- Ensure your TV and sooka TV Stick are switched off before connecting it to your TV.
- Do not insert and switch on Power Adapter before connecting the USB cable to your sooka TV Stick.

What's in the box:



sooka TV Stick



Remote Control
Batteries inside



Power Supply



Welcome Card &
Quick User Guide

Product Specification

Model Number	sooka TV v1
Audio/Video Port	HDMI 2.0 with HDCP 2.2
WiFi	WiFi 6
Bluetooth	Bluetooth 5.0
Electrical Rating	5V 2A
Operating Temperature	5-45°C
Operating Humidity	5~90%



Dolby Atmos Logo Usage approval

Dolby, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories.

Additional Information

A full user guide for sooka TV Stick can be found at <https://sooka.my/faq/device>

